
DESIGN + ENGINEERING GROHE GERMANY

99.1935.031/ÄM 256105/05.23

www.grohe.com







48 607 *48 543 *26 770 *48 543 +8 07 002 48 609 49 086 -14 165 - 08 565 -48 608

Application

for shower

Can be used in conjunction with:

- · Pressurised storage heaters
- Thermally controlled instantaneous heaters
- Hydraulically controlled instantaneous heaters

Operation with unpressurised storage heaters (open water heaters) is not possible.

Specifications

 Flow pressure min. 50 kPa - recommended 100 - 500 kPa

 Operating pressure max. 500 kPa

If static pressure is greater than 500 kPa, fit pressure reducer. Avoid major pressure differences between hot and cold water supply.

• Flow rate at 300 kPa flow pressure approx. 7.5 L/min

Installation

Flush piping system prior and after installation of fitting thoroughly (Consider EN 806)!

This product must be installed in conformance with local codes e.g. AS/NZS 3500 series of standard!

Installation and connection, see Figs. [1] to [8].

Open cold and hot water supply and check connections for leakage!

Maintenance, see Fig. [9].

