LINEARE


DESIGN + ENGINEERING GROHE GERMANY


99.1296.031/ÄM 243799/10.19


Pure Freude an Wasser





www.grohe.com











Application

- 23 839 and 29 135: for basin
- 29 171: for bath

Specification:

• Flow rate at 300 kPa flow pressure

Installation Remove the

Remove the fitting template, see Fig. [1].

Flush piping system prior and after installation of fitting thoroughly (Consider EN 806)!

This product must be installed in conformance with local codes e.g. AS/NZS 3500 series of standard!

Flow rate limiter

This mixer is fitted with a flow rate limiter, permitting an infinitely individual variable reduction in the flow rate.

The highest possible flow rate is set by the factory before despatch.

The use of flow rate limiters in combination with hydraulic instantaneous water heaters is not recommended.

For commissioning, see Fig. [2].

Installation, see Figs. [1] - [9].

Determine dimension **"Y"** from upper edge of concealed mixer housing to the face of tiles.

Cut connection nipple to length so that the installation dimension is **"Y" + 44mm**.

Using a 13mm key, screw the connection nipple into the concealed housing so that the installation dimension is **29mm**. Tighten spout from behind using a 2.5mm allen key.

Open cold and hot-water supply and check connections for watertightness!



basin: approx. 5 L/min

bath: approx. 15 L/min

Check fitting for correct operation.



Maintenance

³ Inspect and clean all parts, replace as necessary and grease with special grease.

Shut off cold and hot water supply!



Replacement parts (* = special accessories).

Care

For directions on the care of this fitting, refer to the accompanying Care Instructions.

AUS

Reece Australia Pty Ltd 118 Burwood Hwy Burwood VIC 3125

Tel.: +61 3 9274 0000 Email: admin@reece.com.au



NZ

Robertson 25 Vestey Drive Mt Wellington, Auckland

Tel.: +64 9 5730490 Email: sales@robertson.co.nz